



USER MANUAL
1st generation
electrofusion welding units

Manufacturer: **CLEVELINGS s.r.o.**
K Pahrsku 1562, 763 61 Napajedla
Tel./fax. +420 573 033 029, mob.: +420 604 196 840
www.clevelings.cz, e-mail: info@clevelings.cz

Contents

1. GENERAL INFORMATION	2
1.1 Signs used in the instruction.....	2
1.2 Use.....	2
2. SAFETY.....	3
2.1 General safety systems.....	3
2.2 Workplace safety.....	3
2.3 Electrical safety	4
2.4 Personnel safety	4
2.5 Use.....	4
2.6 Possible danger sources	4
2.7 Power supply	5
2.8 Power generators.....	5
2.9 Extension cords.....	6
2.10 Servicing	6
3. TECHNICAL SPECIFICATION	6
3.1 Construction	7
3.1.1 Construction (outside)	7
3.1.2 Front panel layout.....	8
3.1.3 Connection adaptors.....	8
3.1.4 Identification plates	9
3.1.5 Barcode scanner.....	9
3.1.6 Acoustic signal.....	10
3.1.7 Keypad.....	10
3.2 Start-up.....	10
3.2.1 Transport, packing and storage	10
3.2.2. Operating personnel	10
3.2.3. Start-up procedure.....	10
4. WELDING PROCESS	11
5. OPERATING INSTRUCTIONS	12
5.1 Starting messages	12
5.2 Welding.....	13
5.3 Settings.....	15
6. TROUBLESHOOTING	17
7. MAINTENANCE	19
8. FINAL REMARKS.....	20
9. FORBIDDEN ACTIONS.....	20
10. FIREFIGHTING INSTRUCTIONS.....	20

1. GENERAL INFORMATION



NOTE

Before proceeding to work with the device make sure to read closely this user manual, which constitutes integral part of the device. The instruction shall be used before work, during and after the launch and anytime it's deemed to be necessary.

Following above instructions is the only way to achieve three main objectives of this instruction manual i.e.:

- Optimization of work effects and performance of the device
- Protection against injuries
- Protection against damage and destruction of the device

1.1 Signs used in the instruction

Present instruction include following safety signs and warnings.

Symbol	Description
	WARNING This symbol refers to a direct threat to the life or health of a person. Ignoring the warning results in serious injuries and may even have fatal consequences.
	CAUTION This symbol provides important information referring to proper operating of the device. Ignoring this message might lead to a malfunction, damaging the material or damages done to the environment.
	INFORMATION This symbol provides instructions and valuable information. Such information will help you to use the machine functions in optimal way.

1.2 Use

Electrofusion welding unit serves for joining of plastic pipes and fittings. Using the device for purposes other than the ones described in this manual is forbidden and can be dangerous to the operator and assisting personnel or can lead to damaging the device or other equipment located in the area.

In order to use the device accordingly make sure to follow:

- all recommendations included in this user manual
- general and detailed guidelines on electrofusion fittings
- applicable health and safety regulations, environmental protection regulations, legal regulations and all standards, laws and directives in force in a given country

Electrofusion welding consist in joining two (PP, PE) pipe ends with the use of electrofusion fitting like e.g. couplers, tees, reductions, saddles, etc. During welding process the device provides electric energy of strictly defined parameters to the resistance wire located on the inner surface of the fitting. Electric energy is transformed into heat causing the polyethylene on the fitting and fitting to melt and bond by filling up the space between both elements. After cooling and crystallization of polyethylene, the connection is durable, firm and reliable.

Electrofusion welding process is performed correctly only if device applied for this purpose allows for full control of process parameters such as:

- welding voltage
- duration of subsequent stages of welding process

Stage of process	Description
I	Preparation of pipes
II	Installation of pipe-fitting assembly in aligning tool
III	Welding
IV	Cooling

2. SAFETY

2.1 General safety systems



WARNING

Every operator is obliged to read the user manual before proceeding to work with the device. During work operator shall use direct protection measures required in the workplace.



Electrofusion welding unit is designed accordingly with current regulations and shall be used exclusively for welding pipes and fittings made of polyolefins. Electrofusion welding process does not pose any danger to the operator provided that the safety rules are followed. However, using the device by unqualified personnel or not following the safety rules could lead to injuries.



WARNING

Device shall be used only by properly trained personnel with suitable qualifications. Using the device against its original purpose is forbidden and might be dangerous to the operator and assisting personnel and could lead to damaging the device or other equipment in the closest area.

All people not involved into the process shall make sure to maintain safe distance while the device is working.



CAUTION

Each unauthorized use of the device, use against its purpose or any interference into its construction will result with immediate loss of warranty.

Improper handling or improper use of the device could lead to:

- Threat to the health and life of the operator
- Damage to the electrofusion welding unit
- Decrease in work efficiency of the welding unit
- Obtaining low quality connections

2.2 Workplace safety

- Workplace shall be kept clean and properly lit. Disorder and improper lighting in the workplace can lead to accidents.
- Do not use power tools in the explosive zone areas with flammable gases, liquids or dusts. Power tools might generate sparks which could ignite them.
- Do not allow children of any 3rd parties in the working area. Their presence could distract the operator which could lead to losing control over the device.

2.3 Electrical safety

- Power supply plug must fit the socket perfectly and cannot be modified in any way. Power tool that require protective grounding cannot be powered through extension cords. Use of unmodified plugs and proper sockets significantly reduce the risk of sustaining an electric shock.
- Avoid touching non-grounded elements, e.g. pipes. Grounding one's body increases the danger of sustaining an electric shock.
- Do not expose power tools to moisture or rain. The penetration of water inside the power tool increases the risk of sustaining an electric shock.
- Power supply cable does not serve for: transport purposes, hanging or lifting the device, pulling the plug out of socket. Protect the power supply cable against high temperatures, sharp edges, oils and moving elements. Damaged or entangled cable increases the risk of sustaining an electric shock.
- During work on the outside, when it's necessary to use extension cables make sure to use extension cables intended for outside use. Using such type of extension cable decreases the risk of electric shock.
- If you are working in high humidity conditions use a circuit breaker. The use of a current protection switch reduces the risk of electric shock.

2.4 Personnel safety

- Be attentive, pay attention to performed actions, take reasonable care while working with power tools. Do not use power tools if you are tired or under the influence of drugs, alcohol or medication.
- Wear personal protective equipment and always safety goggles. The use of personal protective equipment such as non-slip footwear, a protective helmet or hearing protection, depending on the power tool used, reduces the risk of injury.
- Eliminate the possibility of accidental start of the device. Before connecting to the power outlet and before touching or moving the device make sure it's turned off. Moving an electrical device with your finger on the switch or attempting to connect to a power outlet while the equipment is turned on may lead to an accident.
- Avoid unnatural body positions during work. Ensure a safe standing position and keep your balance at all times. This will allow you to better control the power tool in unexpected situations.

2.5 Use

- Do not overload the device. For each work use suitably selected tools. Properly selected tools allow for easier and more confident work in desired power range.
- Do not use power tools with damaged power switch. Device that doesn't allow for emergency shutdown at any given moment poses a danger and shall get repaired.
- Before preparing the device for work, replacing accessories or putting the device back make sure to remove the plug from power outlet. These safety precautions prevent from accidental start of the device.
- Unused power tools shall be stored away from the reach of children. Do not allow people unfamiliar with the device, or this instruction manual, to operate it. Power tools in the hands of inexperienced personnel could be dangerous.
- Take care of the power tools. Damaged parts shall be replaced by authorized service centers. Many accidents are attributed to improper maintenance.
- Use the device in accordance with these instructions. The operating conditions and the type of operation to be carried out must be taken into account. Using power tools for other purposes than intended may lead to dangerous situations.

2.6 Possible danger sources



WARNING

Danger of sustaining an electric shock from elements under voltage. Danger to health and life.

Electrofusion welding unit is an electrical device and thus it's forbidden to:

- leave the device unattended
- use damaged device (casing, cables, extensions)

- service the device that is under voltage
- work with the device on voltage different that intended
- remove safety equipment during welding process



WARNING

Danger of fire or explosion in case of contact with flammable materials.

Electrofusion unit shall be used in accordance with general safety rules. There should be proper ventilation ensured in the place of work and enough space for operation to be carried in safe manner. If the work is carried outside suitable measures shall be taken to protect the device against weather conditions. It's forbidden to use the device in the proximity of flammable substances, explosive zones, excessively hot or cold conditions or in too high humidity or with high level of dust.

It's forbidden to clean the device with the use of solvents or other aggressive substances which could permanently damage the external surface or damage the plastic elements. Only trained personnel can use the device. All repairs shall be performed by qualified personnel.

2.7 Power supply

1st generation electrofusion welding units are adapted to work with power supply AC 230V (+/-15%), 50Hz (+/-10%) from mains or power generator. In case of working in outdoors conditions (construction site) electric sockets should ensure stable parameters of power supply. Power generator or mains to which the device is connected should be equipped (depending on model) with (delay) safety fuses 16A or 20A.



INFORMATION

Before connecting the device to power outlet make sure the power supply parameters are within the range of work of the device – **195 do 265 V!**



WARNING

230V power supply should have grounding wire, residual current circuit breaker and overcurrent protection. It's forbidden to connect the device to power outlets without neutral wire and grounding pin.

2.8 Power generators

Before connecting the device to power generator make sure it's recommended for work on the building site. Follow the user manual delivered with the generator. Connect the electrofusion unit to the generator at least 1 minute after starting the generator. Do not connect other power tools to the generator during welding process.

After finishing the welding process firstly turn off the welding unit main switch, then unplug the device from generator and lastly turn off the power generator. Following this sequence will protect the welding unit from damaging it with voltage peaks which appear during start-up and shut down of power generator.

Required nominal power of the power generator depends on:

- fitting resistance and welding voltage
- outside conditions
- connection



INFORMATION

Different types of power generators often show different regulating characteristics. As a result selecting the power generator basing solely on nominal power might not be effective. When in doubt whether given power generator is suitable for work with the electrofusion unit contact authorized service department.

2.9 Extension cords

Poniższa tabela przedstawia zmianę wymaganego przekroju przedłużacza w zależności od jego długości.

Length	Cross-section
up to 50 m	2,5mm ²
up to 100m	4 mm ²



INFORMATION

In order to minimize the risk of overheating the extension cord, make sure to unfold it!

2.10 Servicing



WARNING

Repairs of power tools shall be performed by professionals and only with the use of original spare parts. This allows to keep the devices safe in use.

3. TECHNICAL SPECIFICATION

Technical parameters	
Type:	BLUEBOX 1.0
Approximate diameter range:	~160mm
Power supply [V]:	230
Input voltage [V]:	195 – 255
Frequency range [Hz]	45 – 55
Max. welding current [A]:	60
Max. fitting power [W]:	1450
Weight [kg]:	13
Protection class:	IP-54
Power supply cable [m]:	3
Welding cables [m]:	3
Dimensions [mm]:	390 x 240 x 160
Voltage regulation range [V]:	8 – 44
Volt. regulation step of change [V]:	0,1
Welding time step of change [s]:	1
Cooling time step of change [min]:	1
Working temperature [°C]:	- 5 to + 40
Recommended power generator [kW]:	3
Welding data registration and traceability:	-
Memory capacity:	-

* only when full cooling times are maintained

3.1 Construction


Electrofusion welding units BLUEBOX 1.0 are equipped with ABS-made casing permanently embedded in steel transport box.. CPU board, power board, transformer and display are all mounted inside the casing. CPU board is responsible for controlling the functions of the device by measuring the voltage and current and controls the duration of subsequent stages of welding process. Device is equipped with outside temperature sensor (located on output cables) and sensor of temperature of transformer which control its temperature and prevents the device from overheating.

Basic elements of electrofusion unit and its control panel are shown below.

3.1.1 Construction (outside)




3.1.2 Front panel layout



3.1.3 Connection adaptors

Electrofusion welding units are equipped with two output cables ended with threaded connectors on which adaptors are to be mounted. In standard each device is delivered with set of two adaptors $\varnothing 4$ and two adaptors $\varnothing 4,7$.





INFORMATION

In order to allow for easier identification of adaptor size, adaptors 4,7mm are market with a groove on its housing. Adaptors 4mm have plain housing with no marks.



INFORMATION

Before each welding process make sure to check the correctness of montage of adaptors on output cables. Pay special attention on choosing the right adaptors in relation to the pins located on the fitting. In case wrong adaptors are used it might happen that welding process will not start, will get aborted or will be carried in incorrect way.

3.1.4 Identification plates

Identification plate includes technical characteristics of given model and unique serial number of the device. The plate is attached to the front part of metal transport case in models BLUEBOX 1.0.

3.1.5 Barcode scanner

Barcode scanner constitutes part of additional equipment options. It's connected to the welding unit via M12 port. Barcode scanner uses a laser beam to scan and decode the information contained in the barcode. Barcode scanner is activated when device is in main menu or in barcode scanner mode. Just point the scanner at the barcode and press the read button. The barcode is scanned by a red laser beam that must pass through the entire barcode, perpendicular to the barcode line, possibly through the center of it. The barcode will not be read correctly if the red light beam does not pass through the entire barcode. Optimum reading results are obtained when the scanner is placed in close proximity to the barcode.



Incorrectly printed or slightly damaged barcodes can be read by placing the scanner directly over the barcode, and then, with the read button pressed, slide the scanner over the barcode. When the barcode is correctly read, the device will emit a sound signal and the screen will display information about the decoded welding parameters.



INFORMATION

Protect the tip of the reader and the scanner window from damage and contamination! The state of the scanner window directly affects the operation of the scanner.

3.1.6 Acoustic signal

1st generation electrofusion welding units use acoustic signal as a confirmation of certain actions performed by the operator. These signals serve as a confirmation of correctly scanned barcode, finishing the welding process or error signalization.

3.1.7 Keypad

1st generation electrofusion welding units are equipped with keypad allowing to control the device, the keypad consists of following elements:

Buttons 1-9 serve for inserting information about welding parameters, or editing the operator/site names

Arrow buttons – allow to navigate through the menu

START button – start welding process

STOP – stop welding process or return to previous screen

PRINT – start printing the protocol with the use of thermic printer or edit the name of operator/site (option available only in units with memory)

3.2 Start-up

3.2.1 Transport, packing and storage

Electrofusion welding units, depending on the model, are originally packaged in cartoon or wooden box. The box is suitably marked to indicate the correct position for transport and storage.



CAUTION

Remember to protect the device against exposure to water (rain, flood), low temperatures and high humidity during work, transport and storage. It's advised to transport the device with 'covered' means of transport.

Electrofusion welding unit shall be kept in horizontal position in well air-conditioned spaces, protected against inadequate weather conditions and meeting the firefighting requirements. Device shall be stored in temperature -10°C to +55°C and air humidity shall not exceed 95%.

3.2.2. Operating personnel

Electrofusion welding unit should be operated by at least one operator with actual certificate of qualification allowing for joining PE pipes with electrofusion welding method, proper training and being aware that improper steering could, in extreme cases, lead to injury or even death of bystanders.


3.2.3. Start-up procedure

1. Make sure that power supply cable is disconnected from power outlet and the main switch is in "0" OFF position.
2. Check the overall condition of the device and electric cables
3. Ensure 230V, 50Hz stable power supply source – from the mains or from power generator of suitable power (detailed info on p. 8)
4. Install suitable adaptors on the output cables
5. Set the welding unit in the welding area

6. Connect the power supply cable to the AC power outlet.
7. Turn on the device by turning the main switch to position "1" ON

4. WELDING PROCESS

The electrofusion welding process is based on the use of heat, which is released when the current flows through the resistance wire to heat the inner surface of the fitting and the outer surface of the pipe. The following picture shows how such connection is formed.



Electrofusion welding process shall be carried accordingly to below general instructions and specific recommendations provided by the fitting manufacturer:








1. Prepare the welding area
2. Clean the pipe ends
3. Cut the end of the pipe perpendicular to its axis
4. If the pipe isn't round use special re-rounding tool
5. Verify if the fitting parameters match the pipe (diameter and SDR)
6. Mark the pipe insertion depth, or in case of saddles - the scraping area, with a marker.
7. Scrape the layer of 0,1-0,2 mm until the marker traces are no longer visible. It's recommended to scrape even further beyond marked area so that there is no doubt about the operation. Scraping marks should be visible on both sides of welded fitting, or around the saddle.
8. Verify the correctness of scraping (removing oxidized layer of PE)
9. Clean the pipe inner and outer surface and inner surface of the fitting with suitable cleaning agent e.g. isopropyl alcohol soaked in absorbent, lint-free, non-pigmented material.
10. Mark the pipe insertion depth once again
11. Insert the pipes into the fitting and verify the insertion depth. All elements must be dry.
12. Fix the assembly in an aligner to ensure firm holding, in case of saddles – mount them accordingly to the instructions of manufacturer.

13. Make sure if the welding unit has CE marking, valid calibration certificate and verify if the power supply source provides correct parameters.
14. Connect the output cables to the fitting
15. Make sure the electrofusion adaptors match the fitting's pins
16. If the device is equipped with additional options such as barcode scanner or thermal printer make sure to connect them before turning on the welding unit.
17. Turn on the electrofusion welding unit
18. Adjust the welding parameters accordingly to the data provided on the fitting
19. Launch the welding process
20. Make sure that the process went smooth without any interruptions (no warning messages displayed)
21. Leave the assembly inside the aligner for the time of 1,5e [min] (e- pipe wall thickness)
22. Once the process is finished turn off the welding unit and pull out the output cables.
23. Mark the pipe with joint number, date of welding, and number of welder's qualification certificate
24. Enter the parameters of performed joint onto the welding protocol if the machine has no internal memory storage.












5. OPERATING INSTRUCTIONS










5.1 Starting messages

Turn the main switch to position "1" ON. If the power supply voltage fits within required range device will start and be ready for work.

	LAUNCH SCREEN On the screen are displayed following information: device type (model) and its serial number
	OWNER INFO <div data-bbox="512 1227 624 1339" data-label="Image"> </div> INFORMATION Changing the owner's name is possible from the level welding machine settings. Detailed description in the further part of the manual.
	PIN REQUEST <div data-bbox="512 1541 624 1653" data-label="Image"> </div> INFORMATION If the PIN request function is turned on you will need to enter the PIN code before accessing the main menu. PIN code is located on the warranty card delivered together with the device. User cannot change the PIN code. Pin code request can be turned off from the menu level. In order to enter the code use keypad and then press  to confirm.
	MAIN SCREEN Once the device is turned on it will display the main menu screen. Use   buttons to choose between MENU and WELD functions.

5.2 Welding











WORK MODES	
<div>WORK MODE <MANUAL></div> <div>WORK MODE <SCANNER></div> <div>WORK MODE <MANUAL BARCODE></div> <div>WORK MODE <AS PREVIOUSLY></div>	<p>Electrofusion welder allows for work in four modes, three of which are operated manually and these are: 'manual', 'manual barcode' and 'as previously'. Barcode scanner is available only for operators that are equipped with barcode scanner.</p> <p>Use   buttons to choose desired work mode and press  to confirm.</p>
MANUAL MODE	
<div>WELDING VOLTAGE U=39,5 [V]</div> <div>HEATING TIME Tg=0025[s] To=22</div> <div>COOLING TIME Ts=0025 [min]</div>	<p>In manual mode operator has to enter all relevant parameters of welding process: welding voltage, welding time, and cooling time. The parameters shall be taken directly from electrofusion fitting or from special card provided by the manufacturer.</p> <div> <div></div> <div> <p>INFORMATION</p> <p>When entering the heating time make sure to correct this value with consideration to outside temperature. Outside temperature is indicated on the screen as 'To'.</p> </div> </div> <p>To enter required information use   buttons and alphanumeric keypad 0-9. Using the arrows choose the character you wish to edit (currently edited character will be highlighted), and then edit the value accordingly. Press  to confirm. In order to return to previous screen press  STOP.</p>
SCANNER MODE	
<div>SCAN THE BARCODE</div>	<div> <div></div> <div> <p>INFORMATION</p> <p>Scanning the barcode can be done from scanner work mode level as well as directly from the main menu screen.</p> </div> </div> <p>In order to scan the barcode correctly direct the laser beam toward the barcode (from suitable distance) and press the button located on the scanner. If the action is performed correctly device will signalize it with short acoustic signal and proceed to the next step.</p>
	<div> <div></div> <div> <p>INFORMATION</p> <p>Laser beam must cover entire length of the barcode.</p> </div> </div> 





		INFORMATION It's advised to adjust the welding parameters through barcode scanner or by entering the barcode manually. Both methods speed up the welding process and eliminate the possibility of human error and automatically adjust the heating time depending on the outside temperature.
		INFORMATION If there is no information in the barcode about cooling time, second fitting diameter or fitting type, device will display a message asking to fill these information manually.
	BARCODE MANUAL In manual barcode mode operator can enter the numerical code located underneath the barcode manually (in case the scanner is damaged or there isn't one). Enter the code using alphanumeric keypad and confirm with  .	
	AS PREVIOUSLY Last work mode allows the operator to reuse the welding parameters from last correctly performed weld. Choosing this work mode will allow you to skip entering the welding parameters and automatically proceed to the next step.	
	POWER SOURCE Before beginning the welding process operator has to select the power source to which the machine is connected.	
		INFORMATION Selection of power source is related with control mode that is used during welding process (see page 21) and choosing wrong type of power source might affect the welding process.
	SUMMARY AND ADDITIONAL INFORMATION Once the welding parameters are entered device will ask if an aligner is being applied for the process.	
	Next, device will proceed to summary screen showing all previously entered parameters. Press START to begin the welding process	
		WARNING Operator should verify if entered parameters are correct. Starting the welding process using inadequate parameters could pose a direct threat to one's health and life. Welding process can be aborted at any given moment by pressing STOP button or turning it off with main power switch. If the welding process gets aborted with STOP button such information will be saved in the welding protocol, whereas when the process is aborted by turning off the device no information will be saved in the memory.

	FITTING TEST	
	<p>Before starting the welding process the welding unit will perform a short test of connected fitting to confirm that the right type of fitting is connected. During the test device measures the fitting resistance and compares it with the resistance encoded in the barcode.</p> <p>In case no discrepancies have been detected device will proceed and begin the welding process. If however device detects discrepancies between the resistance encoded in the barcode and the actual measured value device will display an error message. Because the resistance might change depending on outside conditions error message doesn't necessarily mean there is a problem, especially in case of smaller diameter fittings. If the operator is certain that the welding parameters are correct he can force the welding process by skipping/ignoring the error messages and continuing the work.</p>	
		<p>INFORMATION</p> <p>Fitting test will not be carried in three cases:</p> <ul style="list-style-type: none"> • Welding parameters were set manually • The energy delivered to the fitting during the test might damage the fitting (applies mostly to small diameter fittings e.g. 20, 25mm which have short heating time and low welding voltage) • Resistance encoded in the barcode is saved as non-controlled parameter (resistance equal to 0 Ohm)
	<p>Last message before actual welding process the device counts down the time to starting the welding process. During this time the operator has the possibility to abort the process by pressing the STOP button.</p>	
	<p>When the process is complete, the welding machine will automatically start the programmed cooling time. For welding machines with parameter recording, the interruption of this process by pressing a button STOP will be recorded in the protocol.</p>	

5.3 SETTINGS



	SETTINGS
	<p>User can modify some of the basic settings in the SETTINGS menu.</p>
	DISPLAY
	<p>In display settings user can turn on/off the backlight by pressing one of buttons while in BACKLIGHT menu. Press to proceed to brightness settings. In order to adjust the brightness use buttons.</p>

<div>SETTINGS 2. DATE AND TIME</div> <div>SET DATE/TIME 2018-02-05 08:55</div>	<div>DATE AND TIME</div> <p>Next, are the date and time settings. In order to adjust the values use alphanumeric keypad. Currently edited character is marked by flashing rectangle. Using arrow buttons choose the character you wish to edit and then, using alphanumeric buttons, edit the value. Press  to confirm. In order to return to previous screen press   STOP</p>
<div>SETTINGS 3. OWNER</div>	<div>OWNER</div> <p>Changing the owner info can be done in two ways – using the NT Connection software or directly on the device. In case of the second method use alphanumeric keypad to enter desired information. Currently edited character is marked by flashing rectangle. Using arrow buttons choose the character you wish to edit and then, using alphanumeric buttons, edit the value. Press  to confirm. In order to return to previous screen press   STOP.</p>
<div>SETTINGS 3. CALIBRATION TO</div> <div>CALIBRATION TO 2018-05-02</div>	<div>CALIBRATION CHECK</div> <p>The user can also check the calibration validity date. Additionally device will display a reminder few days before expiration of calibration certificate.</p> <div> <div data-bbox="507 965 603 1055"></div> <div data-bbox="635 869 831 898">INFORMATION</div> <p>30 days before the calibration ends within each start-up device will display a message that calibration will soon expire. Once the calibration expires device will show message: calibration expired. Devices with expired calibration aren't automatically stopped. They will continue to work but each weld recorded in the memory will be described as performed on non-calibrated device. Manufacturer takes no responsibility for welds performed on devices without valid calibration certificate.</p> </div>
<div>SETTINGS 5. ABOUT DEVICE</div> <div>BLUEBOX 1.0 0000/2022 3.0.0.</div>	<div>ABOUT DEVICE</div> <p>In settings menu you can also check the device information which include: device type, serial number and software version.</p>
<div>SETTINGS 6. LANGUAGE</div> <div>LANGUAGE <EN></div>	<div>LANGUAGE</div> <p>Using   buttons user can choose between available language versions.</p> <p>Press  to confirm.</p>
<div>CONTROL MODE FAST</div> <div>CONTROL MODE NORMAL</div>	<div>CONTROL MODE</div> <p>Operator, before starting the welding process has the option to choose between two control modes:</p> <ul style="list-style-type: none"> - Fast mode – required welding voltage is reached in shortest time possible - Normal mode – required welding voltage is reached gradually, in relatively longer time than in case of fast control mode. The aim of using normal mode is to eliminate the issues with stable work of power generator.

		INFORMATION Fast mode is used always when machine is powered from the electrical grid. Normal mode (if power source was correctly selected in settings menu) is used only when power source was selected as power generator.
<div>SETTINGS 7. TRACEABILITY</div> <div>TRACEABILITY <YES NO></div>	TRACEABILITY* Device allows to record fitting and/or pipe information saved within the barcode. By default this option is deactivated. Using   buttons user can turn the traceability on/off.	
<div>SETTINGS 8. PIN REQUEST</div> <div>PIN REQUEST <YES NO></div>		INFORMATION PIN code is located on the warranty card delivered together with the device. PIN code is a factory set value and cannot be modified by the user. Devices for some markets are delivered without the feature of PIN protection.
<div>SETTINGS 10. FITTING TEST</div> <div>FITTING TEST <YES>/<NO></div>	FITTING TEST In the device there is an option to turn on/turn off the fitting test, which is make before the start of welding process (description page 23).	

6. TROUBLESHOOTING

Message	Symptom	Possible cause	Solution
<div>FITTING NOT DETECTED</div>	1. Device isn't welding	1. Damaged fitting	1. Use new fitting
		2. Damaged or mismatched output adaptors	2. Check the condition of adaptors, match the right adaptors in relation to the fitting output pin
		3. Damaged cable	3. Deliver the device for service
<div>TRANSFORMATOR TEMPERATURE</div> <div>OUTSIDE RANGE</div>	1. Device isn't welding	1. Too high/low temperature of the transformer. Large amount of welds performed one after another without breaks for cooling time	1. Leave the device in shaded area until the temperature returns to allowed level
		2. Damaged temperature sensor of the transformer	2. Deliver the device for service

<div>OUTSIDE TEMP. OUT OF RANGE SKIP></div>		1. Too high/low outside temperature. Allowed temperature range 0-40°C	1. Make sure to level out the outside temperature to adequate by e.g. protecting the device against direct sunlight, welding in protective tent.
		2. Damaged sensor of outside temperature	2. Deliver the device for service
<div></div>	INFORMATION There is an option to perform welding in emergency situations, even if the temperature is outside allowed range. For that purpose choose SKIP option by pressing the -> button. Weld performed in such conditions will be saved in the memory with adequate error code.		
<div>PROCESS ABORTED</div>	1. Welding process got aborted	1. Damaged fitting	1. Perform new weld
		2. Output cable disconnected from the fitting during welding process	2. Perform new weld
		3. Damaged output cable	3. Deliver the device for service
<div>FITTING NOT SUPPORTED</div>	1. Device doesn't allow to start welding process	1. Welding voltage or fitting resistance are outside device working range	1. Replace the fitting with the one that is within the working range of the welding unit or use welding unit with higher working parameters.
<div>INCORRECT BARCODE</div>	1. Device doesn't start welding process	1. Entered barcode is incorrect	1. Enter the barcode again or perform the welding process in manual mode
<div>INCORRECT PIN CODE</div>	1. Device doesn't start	1. Entered PIN code is incorrect	1. Correct PIN code can be found on the warranty card
<div>CALIBRATION ALMOST EXPIRED</div>		1. Calibration will soon expire	1. Contact service department to arrange calibration check
		2. Invalid date and time	2. Check date and time settings in device setting menu. If the problem keeps occurring deliver the device for service to replace the internal battery.
<div>CALIBRATION EXPIRED</div>		1. Calibration got expired	1. Contact service department to arrange calibration check
		2. Invalid date and time	2. Check date and time settings in device setting menu. If the problem keeps occurring deliver the device for service.
<div></div>	INFORMATION Whenever the calibration expires, the device won't stop working, and will return to normal work after displaying message about expired calibration. Welds performed on welding unit without valid calibration certificate are saved in the memory with adequate error code.		
	1. Device doesn't start	1. Mains voltage is above acceptable level of 265 V.	1. Check the mains parameters

MAINS VOLTAGE TOO HIGH		2. Power generator isn't working in stable manner	2. Send the power generator for service
		3. Damaged component	3. Deliver the device for service
MAINS VOLTAGE TOO LOW	1. Device doesn't start	1. Mains voltage is below acceptable level of 195 V.	1. Check the mains parameters
		2. Power generator isn't working in stable manner	2. Send the power generator for service
		3. Damaged component	3. Deliver the device for service
OVERLOAD	1. Welding cannot be carried	1. Welding current is outside working range of the device	1. Short-circuit in welding circuit
			2. Use welding unit of higher power or fitting with lower power demand
			3. Damaged welding unit – send the device for service
BROKEN CIRCUIT	1. Welding process got aborted	1. Cables got disconnected during welding process	1. Repeat the welding cycle
		2. Damaged cable/s.	2. Deliver the device for service
FREQUENCY OUTSIDE RANGE	1. Welding cannot be carried	1. Supply current frequency is outside allowed range	1. Check the mains/generator
		2. Damaged welding unit	2. Deliver the device for service

7. MAINTENANCE



DANGER

Each maintenance work shall be performed while the power supply are disconnected from power outlet.

Use and maintenance

Device doesn't require any special maintenance conditions, except for keeping it in general cleanness. Standard maintenance works are limited to periodical cleaning of external surfaces of the device.

Electrical components

Pay special attention during storage, use and transport that the electrical components are not exposed to water (rain, drowning) or moisture.

List of wear parts:

1. Electrical components: power supply cables, output cables;
2. Other: adaptors;

In case of failure turn off the device by pull the plug from power outlet. Such fact shall be immediately reported to the superior. Warranty and post-warranty repairs are performed after delivering the device to the producer service department as stated in warranty terms and conditions.

In accordance with requirements and provisions regarding welding devices, the welding unit is subjected to obligatory annual inspection performed by the producer or other authorized entities. During the inspection a complete examination for correct

work of the welder and all necessary repairs are carried out. An appropriate certificate is being issued for that occasion (so called certification of calibration).

8. FINAL REMARKS

1. Each user or the device is absolutely obliged to become acquainted with the user manual;
2. Electrofusion welder can be used only by properly trained and prepared personnel with adequate knowledge about technology of welding polyethylene pipes;
3. Information and remarks included in this instruction manual combined with recommendations of technical inspection allow to perform highly durable connections;
4. The user shall care for proper maintenance, storage and service of both, machine and additional equipment;
5. Device is serviced by the producer free of charge within the warranty period, and post-guarantee (payable) after delivering the device to the place of producer;
6. The Producer is also performing an annual evaluation of technical condition of the product, so called „calibration” for the occasion of which a suitable certificate is issued;
7. The producer reserves the right for performing constructional changes resulting from customer requirements or technical and organizational potential;
8. Making any alterations one's own and removal of the seals without producer's consent is unacceptable and results with loss of guarantee.

9. FORBIDDEN ACTIONS

1. Using the device against its purpose;
2. Using the device with faulty output cables;
3. Repairs and adjustments done by unauthorized personnel;
4. Using the device by untrained and unqualified personnel;
5. Using the device without valid calibration certificate. After 1 year of use device is subjected to mandatory calibration;
6. Using the device against the user manual and welding technology;
7. Using the device in explosive areas;
8. Remarks included in the user manual or resulting from internal regulations;

10. FIREFIGHTING INSTRUCTIONS

1. Welding unit does not have its own firefighting kit. In case of fire use general firefighting equipment should be used.
2. Do not extinguish with water. Use fire-extinguishing blankets or dry powder extinguisher
3. Welding shall be performed in covered places, not exposed to the risk of explosion (e.g. from damaged gas installation).

